



# 11x3 Matrix

## P2.6 40x20 cabinet mapping and power

Resolution	2112 x 1152	Size	18.03 x 9.84
Power	6 (15 amp) outlets	Data	6 Cqt5/6 Network cable



This system use 6 15 Amp separately breaker connected to the main 110 V AC source


Wiring should be distributed Along the screen .

**DO NOT** exceed the max amount of cabinet per outlet

**(MAX 7)**

A PC or windows laptop is need it to program this processor , please download Novastar LTC from Novastar Tech , and install it .

**NOTE :** LAN access is default in processor , GOTO communication



P2.6

192x384

20x40



Processor	VX600
Other	VX1000 or WP150 with cards